

Telematics

Exploded view of telematics system

1. Operating electronics control unit, navigation -J402

- ◆ In centre console
- ◆ Removing and installing
=> Page 91-281


2. Display in dash panel insert

- ◆ In dash panel
- ◆ Removing and installing

=> Electrical System; Repair Group 90; Dash panel insert

3. Front interior light with emergency call button -E276, breakdown help button -E275, hands-free microphone

- ◆ In roof at front
- ◆ Removing and installing
=> Page 91-411



A91-0433

4. Function selection switch -E272

- ◆ In centre console
- ◆ Removing and installing
=> Page 91-342

5. Additional loudspeaker for telematics -R91 (emergency loudspeaker)

- ◆ In B-pillar trim, front passenger's side
- ◆ Removing and installing
=> Page 91-414


6. Telephone handset - R37

- ◆ In centre armrest
- ◆ Removing and installing
=> Page 91-86

7. Navigation aerial -R50

- ◆ On boot lid
- ◆ Removing and

installing
=> Page 91-245



8. Telephone/telematics control unit -J526

- ◆ In luggage compartment beneath rear shelf
- ◆ Removing and installing => Page 91-403

9. GPS aerial filter -R87

- ◆ At telephone/telematics control unit -J526
- ◆ Removing and installing => Page 91-410

10. Rod aerial for telephone


- ◆ At rear left of luggage compartment beneath side trim
- ◆ Removing and installing=>Page 91-62

11. Navigation/TV tuner - J415

- ◆ In left luggage compartment

storage area

- ◆ Removing and installing
- => Page [91-283](#)



12. Language input control unit -J507 (optional)


- ◆ In left luggage compartment storage area
- ◆ Removing and installing
- => Page [91-425](#)

13. Additional aerial for telematics -R90 (emergency aerial)

- ◆ In rear bumper
- ◆ Removing and installing
- => Page [91-415](#)

14. CD changer

- ◆ In left luggage compartment storage area
- ◆ Removing and installing
- => Page [91-64](#)



**15. Hands-free loudspeaker
(up to MY 01)**

- ◆ In driver's B-pillar trim
- ◆ Removing and installing=>Page [91-98](#)
- ◆ Vehicles with BOSE sound system only

16. Treble speaker

- ◆ In top of front door trim
- ◆ Removing and installing=>Page [91-58](#)

17. Mid-range/bass speaker

- ◆ In bottom of front door trim
- ◆ Removing and installing=>Page [91-58](#)

