

Removing and installing left dash panel end trim

Removing

- Use a screwdriver to prise off the left dash panel end trim -arrow-.

Installing

Install in reverse order.

