

Sun roof

Removing and installing wind deflector

- – Move sun roof to rear as far as it will go.
- – → Push wind deflector -1- to rear in direction of arrow and press it out of holder.
- – Press wind deflector towards centre of vehicle until stop -2- beneath sun roof opening is exposed.
- – Lift wind deflector with spring -3- out of sun roof opening.
- – When installing, make sure spring engages properly in frame.

